

Wireless Alerter/Ringer/Flasher

The **Wireless Alerter/Ringer/Flasher** is **100% battery operated**



Wireless Doorbell Alert- press the doorbell button and the alert goes off

Wireless Alert - press the waterproof panic button and the alert goes off

Wireless Telephone Ringer Alerter - when a phone call comes in the alert goes off

3 Functions in 1 Unit

ONLY \$59.99 US + Shipping/Handling

*Prices are subject to Change without Notice

ITEM # atsan7464

Incoming Call Ringer/Flasher Features:

Connect the ringer transmitter box to your phone line and when a call comes in the box will activate and flash and/or ring.

- The range between the transmitter and the ringer box is more than 200 feet with few obstructions
- The signal will go through walls and doors and floors
- Very Loud Ringer 110 dba allows for you to hear the alert all over the house
- 3 ringer tones can be select by a switch. This allows you to choose the tone that fits your needs best.
- Ringer volume control switch (High/Medium/Low)
- Ringer Lights 3 bright LED's
- Can select between ringer only, light only or both ringer and light together
- Power on / off switch
- Both the receiver and transmitter can be wall mounted.
- The receiver is totally battery operated so you can take it anywhere in the house or take it outside so you can know if the phone rings while out in the yard.
- Receiver powered by 3 Batteries LR14 / C Cells Alkaline batteries
- This system uses a common frequency between units (2 or more units will share pendants)
- A total combination of 5 doorbells or panic buttons can be used with this system

Door Bell Features:

- Press the wireless battery powered door bell and the ringer flasher unit will activate and flash and/or ring when the door bell is pressed.

Door bell battery is cn23a 1.2v (included). Battery is easily replaceable. These batteries are easy to find.

Alerter/Panic Button Features:

- Press the wireless waterproof battery powered panic button and the ringer flasher unit will activate and flash and/or ring each time the button is pressed.

Panic Button Battery is cn23a 1.2v (included). Battery is easily replaceable. These batteries are easy to find.



Call Ringer Flasher Only What's Included:

**Battery Powered Ringer/Flasher Unit
Transmitter with telephone line splitter
Screws for optional Wall Mounting
Instruction Manual, 1 Year Factory Warranty**



