

No Land Line Needed - SOS Security Medical Alert System

NO MONTHLY FEES - Personal Medical Alert System



The NEW SOS Alert System has all the features you are looking for today.

- No landline Needed
- Calls For Help When Panic Button Is Pressed
- Remote Monitoring With App
- Setup with Smartphone App
- I'm Home and I'm Away Notification
- Pacemaker Safe - Waterproof (shower or bathe with it)
- 100-150 Foot Range Between Panic Button and Base

No Landline ... No Problem
Works with Cellular Service

ONLY \$229.99 US + Shipping/Handling

*Prices are Subject to Change Without Notice

ITEM # atsgmsos

Features List:

Hands free design

Large Buttons on the keyboard

Built in rechargeable emergency backup. Keeps the system running even when the power is out.

7x24 solution: take care of elderly get up, medical, SOS, fire, smoke, water, gas, sports, bedtime, etc.

Large LCD display. Makes it easy to see the time and status. current time, temperature, and alarm events;

Cellular Based (GSM/GPRS) wireless transmission. You are not tied to your home land line

Comes with 8 speed dial buttons that can be programmed for any number (Friends, Police, 911, etc.)

User can manually dial any number from keyboard.

Make and receive calls from console (just like any normal speakerphone telephone)

Can send Home and Away text messages to notify others of condition

This system is expandable to a home automation and security system. Here are some of the optional features You can enjoy when you purchase some of the optional modules such as: motion detectors, fall detector, CO Detector, smoke detector.:

Bedtime/'Did not get up on time' alarm;

Away/Back home time notice;

Android app and iOS App can display the bedtime and away/back home trends; this helps you keep of movements and living patterns

3-Timer for alerting to take medicine or other activities.

How Does The Emergency Alert Feature Work?

When a panic button is pressed the system will send a text message to the first number in the SMS Alert list (if programmed), (up to 5 numbers can be sent a text)

then the system will call the first number in the Alarm Number list, if no answer, it will call the second number and so on. (up to 5 phone numbers can be called)

Know When They Are Leaving and Know When They Arrive Home.

The system also has a Home and an Away button. When the Away button is pressed the system can send a text that says 'I'm Leaving Now'. And then when the user arrives home they can press the Home button and the system can send a text that says 'I'm Home'. This feature saves time and helps keep you informed.

Great for the elderly and keeping up with kids.



Add Extra Waterproof Panic Buttons.
Only \$29.99 US + Shipping/Handling





ORDER FORM

Assistive Technology Services
 "Helping You Live Independently"

8023 Franklin Road
 Murfreesboro, TN, 37128
 (615) 562-0043
 Fax (831) 308-9671

Billing Address Name _____ Address _____ City _____ State _____ Phone Number _____	Check if same as Billing []	Ship To Address Name _____ Address _____ City _____ State _____ Phone Number _____
---	--	---

CUSTOMER EMAIL ADDRESS	PAYMENT TERMS	DATE
	Due on receipt	

QTY	ITEM #	DESCRIPTION	UNIT PRICE	Shipping to US	Shipping to Canada	Shipping to Other	UNIT TOTAL
	Atsgsmsos	No Land Line Needed - SOS Security Medical Alert System	\$229.99	\$13.89	\$33.89	\$49.99	
	xb-atsgsmsos	Add Extra Waterproof Panic Buttons Necklace	\$29.99	\$5.99	\$15.99	\$25.99	
	xb-atsgsmsos	Add Extra Waterproof Panic Buttons Wrist	\$29.99	\$5.99	\$15.99	\$25.99	
							Subtotal
		Only Applicable If Shipping To Tennessee					TN Sales Tax 9.75%
		*Prices are Subject to Change without Notice					
							Total

If Paying By Check Please Make Checks Payable To: Assistive Technology Services

Credit Card Type	Credit Card Number	Expiration Month	Expiration Year	Security Code From Back Of Card
Visa [] MC [] AmEx [] Disc []				
Name On Card	Email Address			

"May You Know The Glory Of God And May He Bless You"